

DESCRIPTION

Model DP-30L II turntable is an improved version of the original Model DP-30L/30LS, featuring a light mass straight tonearm.

The electrical circuitry and rating are identical to those of original model.

Therefore, refer servicing to the original service manual as the electrical adjustments are exactly same.

PARTS LIST (Deviation from original Model DP-30L)

Part Name	Part No.	Remark
CABINET ASS'Y	[1038221203	North America
	1038221219	Europe/Australia
ARM REST ASS'Y	3158564013	
TONEARM ASS'Y	3158825105	
BALANCE WEIGHT ASS'Y	3158561113	
ARM BASE ASS'Y	3158826104	
SHAFT RING	3158828005	
SHIELD SHEET	4148176009	Phono output
HEAD SHELL ASS'Y	3158553011	PCL-30
SHELL ACCESSORY	3158547001	
CAM	4248009005	ARM LIFTING
VOLUME KNOB	1138078220	Speed adjust
RUBBER SHEET	[4218288005	
(turntable sheet)	4218288018	UL recognized
INSTRUCTION MANUAL	5118221006	
CARTON CASE ASS'Y	5018267005	

Other parts are same or compatibly modified.